



### Fitting the 'A' Frame canopies:

1. Determine the exact position of the fitted canopy and mark out where the brackets are to be fixed.
2. Pre-drill the brackets and fix to the wall using suitable fixings.
3. Hold the canopy in place and mark out the position of the gallows brackets.
4. Take the canopy down and fix the gallows brackets to the wall. Pre-drill the back truss and fix to the wall using suitable fixings.
5. Secure canopy to the brackets.
6. Secure top bar in place to create sturdy apex.
7. The canopy is now ready to tile/thatch/paint to your individual requirements.
8. If using wood turning attach with wood glue.

### Fitting flat roofed canopy:

1. Determine the height required for the underside of the canopy and mark on the wall.
2. Remove ply lid (not yet attached), attach canopy to the wall from inside of canopy, the weight will need to be supported until brackets are secure.
3. Attach ply lid.
4. Determine location of gallows brackets and attach to wall and canopy.
5. Finish as required.

### Fitting mono pitch canopy:

1. Determine where you require the level of the front of your canopy to be and mark off.
2. Measure from this point up to 650mm. Place the top edge of the back plate on this mark and fix to the wall using suitable fixings.
3. Place the brackets at right angles against the wall using suitable fixings.
4. Insert purlin between brackets to fit snugly into cut out notches, screw into place.
5. Evenly space rafters. Screw into place.
6. Screw ply roof into place.
7. The canopy is now ready to be finished as required.

### Outsized bespoke canopies:

**If your canopy does not fit in with our fitting instructions please contact our helpful team.**

**01363 884218**

**[sales@timberdoorcanopies.co.uk](mailto:sales@timberdoorcanopies.co.uk)**